Instructions for maintenance



In addition to the manufacturer-related service instructions, we strongly advise the operator/owner to consider the corresponding prescriptions of the European Standard EN1176-7.



approx. 4-5 weeks after installation

K&K Climbing 055485703 combination

One-time maintenance

necessary

decay, repair or replace if necessary

Check all screw connections; retighten, if necessary.

	Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year
	Check cleanliness of playing and safety area. Remove any foreign object						
	Check chains of spatial climbing net for wear, replace if necessary. The nominal chain thickness must not diminish more than 30% (< 5 mm). Beyond that limit, a chain replacement is indispensable.						
	Check climbing handles for wear, replace if necessary						
	Check cleanliness of sliding surfaces, remove protruding parts, exchange damaged sliding course coverings						
	In case of drying cracks, remove splinters of wood and chamfer sharp edges						
	Where appropriate, check synthetic surfacing material for damages or severe wear, repair or replace, if necessary						
	Check tightness of stand construction: stability of (vertical) posts or supports, retighten screw connections, if necessary.						
	Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.						
	Check tension and damages of the climbing ropes, replace if						

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).

Check tightness/stability of the connection between stainless steel support and laminated timber post, replace post, if necessary.

Check foundations and structural construction for corrosion or