Instructions for maintenance

© 2006 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

K&K 0-57050-001 Log step excerciser



One-time maintenance

Check all screw connections; if necessary screw down again.

one-time only approx. 4-5 weeks after installation


Recommendations about regular maintenance

Check cleanliness of play- and safety area, take out alien elements

Check stability of vertical posts, tighten bolt-connections if necessary

Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary

Check foundation, foundation anchoring and whole construction for corrosion or decay, repair or replace if necessary.



Please note:

The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)