

## Instructions for maintenance

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

## Water 0-34352-501 play structure



Check all screw connections; if necessary srew down again.	one-time only approx. 4-5 weeks after installation								
Recommendations about regular maintenance	1 x weekly	2 x monthly	1 x monthly	4 x yearly	2 x yearly	1 x yearly			
Check cleanliness of play- and safety area, take out alien elements									
Check tightness of stand construction (stability of vertical posts or supports), retighten screw connections, if necessary									
Check further structural components for wear and tightness, retighten, if necessary and replace defective parts.									
Check bearings and/or joints for tight fixing and easy-running function, replace or grease, if necessary									
Check rubber parts like seats, hoses, collars etc. for wear,replace if necessary									
In case of drying cracks, remove splinters of wood and chamfer sharp edges									
Check foundations and structural construction for corrosion or decay, repair or replace if necessary.									



	Check function of lower swivel joint of water spiral, check	 		 	
	specification dimension according to attached drawing, as		$\mathcal{M}$		
	soon as specification is met or overspend, please				
	de-install water spiral and replace complete bearing unit.			 	

## Please request our detailed information for your planning by phone +49(0)4254-93150

Please note: The mentioned maintainance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g.due to the frequency of use, social facilities and vandalism problems etc.)