## Instructions for maintenance

©2007 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

0-41127-000 K&K Freestanding slide (1,60)



## One-time maintenance




Check all screw connections; if necessary screw down again.

Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary Check slide chutes for cleanliness, take out protruding elements,

one-time only approx. 4-5 weeks after installation

## Recommendations about regular maintenance

repair defect sliding sheet metal



## corrosion, repair or replace if necessary.

Please note: The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)