Instructions for maintenance



In addition to the manufacturer-related service instructions, we strongly advise the operator/owner to consider the corresponding prescriptions of the European Standard EN1176-7.



once,

K&K Climbing 023831705 combination

One-time maintenance

Check all screw connections; retighten, if necessary.

Cover screw neads with the protective screw caps furnished.	approx.	approx. 4-5 weeks after installation					
Recommended regular inspection and maintenance	once a week	twice per month	once a month	four times a year	twice a year	once a year	
Where appropriate, clean playing sand							
Check cleanliness of playing and safety area. Remove any foreign object							
Check cleanliness of sliding surfaces, remove protruding parts, exchange damaged sliding course coverings							
In case of drying cracks, remove splinters of wood and chamfer sharp edges							
Where appropriate, check synthetic surfacing material for damages or severe wear, repair or replace, if necessary							
Check tightness of stand construction: stability of (vertical) posts or supports, retighten screw connections, if necessary.							
Check further structural components for wear and tightness; retighten, if necessary and replace defective parts.							
Check tension and damages of ropes and/or nets, replace if necessary							
Check tightness/stability of the connection between stainless steel support and laminated timber post, replace post, if necessary.							
Check foundations and structural construction for corrosion or decay, repair or replace if necessary							

Please note: The above-mentioned maintenance intervals only have recommendatory character. They must necessarily be adapted to the local circumstances of each playground (frequency of use, social setting, risk and frequency of vandalism etc.).