
Instructions for maintenance

© 2008 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

K&K **Trampolin bridge** 0-46650-000



One-time maintenance ES

Check all screw connections; if necessary screw down again.

one-time only approx. 4-5 weeks after installation

Recommendations about regular maintenance

x monthly 1 x month 1 x weekly 4 x yearly 2 x yearly 1 x yearly Check cleanliness of play- and safety area, take out alien elements Check stability of construction, tighten bolt-connections if necessary

Check foundation, foundation anchoring and whole construction for corrosion, repair or replace if necessary.

Check rubber parts like seats, hoses, collars etc. for wear,

Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary

Please note:

replace if necessary

The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)