

Instructions for maintenance

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

Post 0-40190-000 swing (2,00)



Check all screw connections; if necessary srew down again.	after installation					
Recommendations about regular maintenance	1 x weekly	2 x monthly	1 x monthly	4 x yearly	2 x yearly	1 x yearly
Check cleanliness of play- and safety area, take out alien elements						
Check tightness of stand construction (stability of vertical posts or supports), retighten screw connections, if necessary						
Check further structural components for wear and tightness, retighten, if necessary and replace defective parts.						
Check chain suspensions for wear, replace if necessary. The nominal chain thickness must not diminish more than 30% (
Please note that the grub screw inside the chain adapter has to be fully tightened e.g. with an Allen key or a socketwrench without overwinding the screw socket						
Check bearings and/or joints for tight fixing and easy-running function, replace or grease, if necessary						
Check rubber parts like seats, hoses, collars etc. for wear,replace if necessary						

Kaiser & Kühne Freizeitgeräte GmbH

	Check foundations and structural construction for			
	corrosion or decay, repair or replace if necessary.			

Please note: The mentioned maintainance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g.due to the frequency of use, social facilities and vandalism problems etc.)