
Instructions for maintenance

© 2006 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of E N 1176-7



0-37181-000 K&K Effect disc

One-time maintenance						
Check all screw connections; if necessary screw down again. Cover screw-head with protecting cap.	one-time only approx. 4-5 weeks after installation					
Recommendations about regular maintenance	1 x weekly	2 x monthly	1 x monthly	4 x yearly	2 x yearly	1 x yearly
Check cleanliness of play- and safety area, take out alien elements						
Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary						
Check bearings and/or joints for tight fixing and easy-running function						

Please note:

The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g.due to the frequency of use, social facilities and vandalism problems etc.)