

# Instructions for maintenance

© 2007 Kaiser & Kühne Freizeitgeräte GmbH

Im Südlöh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7



## 0-40204-001 K&K Post swing (1,80)

### One-time maintenance



Check all screw connections; if necessary screw down again.

one-time only  
approx. 4-5 weeks after installation

### Recommendations about regular maintenance



Check cleanliness of play- and safety area, take out alien elements

1 x weekly



2 x monthly



1 x monthly



4 x yearly



2 x yearly



1 x yearly



Check stability of vertical posts, tighten bolt-connections if necessary



Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary



Check bearings and/or joints for tight fixing and easy-running function



Check chain suspensions for wear, replace if necessary



**Please pay attention that the cylinder head screw in the chain adapter has to be well screwed down with a ratchet wrench, without overwinding the hexagon socket**



Check rubber parts like seats, hoses, collars etc. for wear, replace if necessary



Check foundation, foundation anchoring and whole construction for corrosion, repair or replace if necessary.



### Please note:

**The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)**