Instructions for maintenance

© 2007 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7



0-30230-500 K&K Sand playspace

One-time maintenance

Check all screw connections; if necessary screw down again.

one-time only approx. 4-5 weeks after installation

Recommendations

about regular maintenance

Check cleanliness of play- and safety area, take out alien elements


Check stability of vertical posts, tighten bolt-connections if necessary

Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary

Clean playsand/playbark

In case of dry shakes remove splinters and brake chamfer edges

Check foundation, foundation anchoring and whole construction for corrosion or decay, repair or replace if necessary.



Please note:

The mentioned maintenance intervals are a recommendation only. They have to be adjusted to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)