Instructions for maintenance

©2007 Kaiser & Kühne Freizeitgeräte GmbH

Im Südloh 5 – D-27324 Eystrup – Telephone 0049/4254/93150 – Fax 0049/4254/931524 – E-Mail info@kaiser-kuehne-play.com

We recommend, in addition to our instructions for maintenance, to consider carefully the demands of EN 1176-7

0-41123-000 K&K Freestanding slide

Recommendations about regular maintenance


Check cleanliness of play- and safety area, take out alien elements

Check stability of vertical posts

Check other component elements for wear and tight connections, tighten connections and replace defective elements if necessary

Check slide chutes for cleanliness, take out protruding elements.

Check foundation, foundation anchoring and whole construction for or decay, repair or replace if necessary.



Please pay attention!

The mentioned maintenance intervals are a recommendation only. They have to be accommodated to the needs and circumstances of a certain playground (e.g. due to the frequency of use, social facilities and vandalism problems etc.)