

## Installation of K&K slide bedways (flange fastening):

- Assign a location for the slide bedway considering the space requirements/impact area. Slide direction recommended: north-east or in half-shade of trees.
- Excavate foundation hole for run-out section according to drawing. To achieve maximum stability and a safe installation, a moderate level of soil solubility is required.
- Use e.g. lifting gear to carry the slide bedway to the mounting place intended and align it (considering all additional details mentioned).
  Fasten flange of slide entrance by using the two holes for M12 screws.
- 4. Grout foundation with compressed concrete C20/25 and insert the anchor screws provided (also see detail).
- 5. Release for play after concrete foundation has set. Cover the foundation with appropriate surfacing material.
- 6. According to maintenance instructions, check all screw connections after 4–5 weeks and retighten, if necessary.

Please ensure that all special tools and specific documents which are or may be useful for safety management (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the persons responsible.

## <u>Some additional instructions for the installation of K&K Bedway slides</u>

- The specified installation height of the slide=hx must be observed (distance between play level and bottom edge of the fastening flange).
- The starting section of the chute must be installed horizontally.
- All (straight, curved or waved sections) of the slide assembly must be installed with the correct inclination (measured in the centre of the slide trough). This does not apply to the run-out section.
- The slide support has to be installed such that it effectively supports the slide, that the curved or waved sections are properly positioned without a deviation from the inclination specified.
- The run-out section must be installed with an inclination of 5°.

## slide support fastening 1:20

consisting of 2 pieces each: security hex screw M12x25-A2; washer DIN 125-13-A2;



Description

Scale

Date

Page

Installation

Item-No. **0-41456-001** 

K&K Bedway slide (2,40)

1:50 08/14 EB

