




\* max. free height of fall

**3 x screw connection****totter platform on compression spring/holder**

consisting of:


mushroom head screw M12x80-DIN603-zinc-plated;  
safety nut M12-DIN985-zinc-plated;**3 x screw connection****compression spring/spring holder on foundation**

consisting of:

hexagon set nut M12x50-DIN931-zinc-plated;  
washer  $\phi$ 13-DIN125-zinc-plated;

1. Mount compression springs with spring holders to the foundation. Mount jumping platform with spring holders to the compression springs. **Also see detailed fotos on the next page.**
2. Assign location of equipment considering the impact area (falling space).
3. Excavate soil for foundation, according to drawing. Please note: To achieve maximum stability and a safe installation, a moderate level of soil solubility is required.
4. **With loose particulate material (e.g. bark, woodchip, gravel or sand), it is essential to establish the foundation on natural ground or on solid and compact substrate as for instance a mineral mixture.**
5. Grout foundation with compressed concrete C20/25, insert pre-assembled unit with foundation anchorage **on a level with top edge of foundation** and align it with spirit level.
6. Due to forced movement, it is essential to cover the impact area with a surface which meets the requirements for impact attenuation so that the critical height of the surfacing shall be equal to or greater than the free height of fall (acc. to EN 1176-1).
7. Check all screw connections according to maintenance instructions after 4-5 weeks and retighten, if necessary.

Please ensure that all special tools (e.g. Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the persons responsible.



**3 x screw connection  
compression spring/spring holder on foundation**  
consisting of:  
hexagon set nut M12x50-DIN931-zinc-plated;  
washer  $\varnothing$ 13-DIN125-zinc-plated;



(illustration of a similar model)



**3 x screw connection  
totter platform on compression spring/holder**  
consisting of:  
mushroom head screw M12x80-DIN603-zinc-plated;  
safety nut M12-DIN985-zinc-plated;