



Item no.	Height
0-52604-700	0,40
0-52606-700	0,60
0-52608-700	0,80
0-52610-700	1,00
0-52612-700	1,20
0-52614-700	1,40

1. Assign location of equipment considering the space requirements/ impact area.
2. Excavate soil for foundations, according to drawing.  
Please note: To achieve maximum stability and a safe installation, a moderate level of soil solubility is required.
3. Pour in a drain layer of gravel of approx. 10 cm thickness between the bottom of the tubular pedestals and plain base of foundation.
4. Insert reinforcing steel into the corresponding hole of the tubular pedestal.
5. Place post according to post number into the respective hole of foundation. Play level mark (= aluminium blind rivet), conforms to the mounting depth of post. Align every post by means of the play level mark facing into the same direction (see detail or foundation layout).
6. Grout foundations with compressed concrete C20/25, chamfer and round off the edges and cover with a surface which meets the requirements for impact attenuation so that the critical fall height of the surfacing is equal to or greater than the free height of fall of the equipment (acc. to EN 1176-1).
7. Release for play after concrete foundations have set.
8. Check all screw connections acc. to maintenance instructions after 4-5 weeks and retighten, if necessary.

Please ensure that all special tools supplied (e.g. Allen key for secured Allen screws etc.) and all specific documents which are or may be useful for safety management acc. to EN 1176-7 (e.g. invoice, delivery note, order acknowledgement, installation instructions, maintenance instructions) are forwarded to the persons responsible.

